

RMS Tank Mount System Mounting Instructions for Radion XR30 and XR15 LED Models



Kit Assembly Instructions


1. Choose appropriate Spacer configuration



2a. If using the RMS on a rimmed tank; leave the included spacer on the clamp chop.

2b. If using the RMS on a rimless tank; slide the included spacer off of the clamp chop.

2. Mount RMS assembly to tank WARNING: Do not over tighten clamp, over-tightening may result in damage to your tank or RMS assembly.




3. Choose appropriate Sliding Rail for desired front to back position *XR15 Kit only includes two Sliding Rails.




4. Insert X-Bracket assembly into the end of the Sliding Rail and tighten down screws



5. Attach Radion to X-Bracket





6. Guide Sliding Rail onto Formed Arm over the locking nut and tighten screw in desired position

